



Congratulations on your purchase of GranSport Performance Brake Pads

**As brakes are safety items that affect the safe operation of your vehicle, we strongly suggest that a licensed technician or highly experienced person familiar with brake pad performance and braking systems install these pads (and associated brake system components) on your vehicle.**

Once installation has been completed, a test drive should be done to ensure proper brake system operation and to “break in” or “burnish” the pads to the rotors.

The “break-in” is a required process, **which must not be overlooked**, in order to achieve optimum performance of your new GranSport pads. To perform the “break-in”, follow the steps listed below:

Step 1: Make 10 stops from 30 mph (50 kph) down to about 10 mph (15 kph) using moderate braking pressure and allowing approximately 30 seconds between stops for cooling. Do not drag your pads during these stops. After the 10<sup>th</sup> stop, allow 15 minutes for your braking system to cool down.

Step 2: Make 5 consecutive stops from 50 mph (80 kph) down to 10 mph (15 kph). After the 5<sup>th</sup> stop, allow your braking system to cool for approximately 30 minutes. This completes the “break-in” of your pads to the rotor surface.

During Steps 1 & 2, a de-gassing process occurs which may produce an odor coming from your pads as they complete the “break-in” cycle. This odor is normal and is part of the process your pads must go through to achieve their ultimate level of performance. The odor will go away after allowing your braking system to cool for approximately 30 minutes.

As with any new set of pads, do not tow a trailer or do any hauling during the “break-in” period.

Full seating of your new brake pads normally occurs within 1000 miles.

Your new pads are now ready for use. **Drive Safely.**

***GranSport***  
P E R F O R M A N C E   B R A K E S